OPERATING MANUAL BATCH COUNTER BC 9611, 7211

MISTURA

Technical Specification:

| | 1 | | | | | |
|-----------------------|---|-------------|----------|-----------------|-----------------------------|--|
| Model | BC 9611 | | | BC 7211 | | |
| Size(HxWxD) | 96 X 96 X 50 mm | | | 72 X 72 X 85 mm | | |
| Panel Cut-out | 92 X 92 mm | | | 68x68 mm | | |
| Display | UPPER:- 6 Digit 7 seg 0.56", Red LED Display LOWER:- 4 Digit 7 seg 0.40", Green LED Display | | | | | |
| Input | NPN/PNP Proximity & Micro Switch | | | | | |
| Output | 1/2 Relay,230V AC, 5A | | | | | |
| Supply | 230V AC, 50 / 60 Hz, Approx. 4VA | | | | | |
| Protection Level | IP-65(Front side) AS per IS/IEC 60529:2001 | | | | | |
| Operating Temperature | | 0°C To 55°C | Relative | Humidity | Up to 95% RH Non Condensing | |

Working :

CH-1

• When set Count reach at set value, Relay will ON.

• Relay will stay on up to Relay Time. After completion of Relay Time, Relay will OFF.

• If Relay Time is set to ZERO then Instrument working in manual mode and user need to press Reset key Relay OFF.

CH-2

- Set Count 1: Advance setting for batch Count.
- Set Count 2: Batch setting.

• when set count Reaches The set count 1, relay will be on, and when it reaches to set count 2, relay will be off & Batch count will be zero.

• Always set the value of Set 1 less then Set 2.

Key Operations:

- Press SET Key to enter in programming mode.
- Press SET Key to go to next parameter.
- Use SHIFT (\leftarrow)Or UP(\uparrow) key to change value of parameter.
- Press RST Key 3 sec. to Reset Batch Count./ Use SHIFT (←) to See Batch Count
- Press RST Key 10 sec. to Reset Batch Count & Total Count

